

Solid State Start Switch SS110C (Combination Motor)



Regaining Sweep Reverse


(AMF 82-70 with SS chassis)

*** In some instances Sweep reverse may be lost after connecting the SS110C. To regain sweep reverse, just perform this simple modification.**

Motors fitted with mechanical switches will continue to run as normal when this modification has been made.


Before modification:

Red wire from sweep motor goes to TSA2.
White wire from common terminal strip goes to motor start capacitors.
Blue wire (R or L133) from Sweep Reverse Switch goes to TS23.



After Modification

Red wire from sweep motor goes to TS23.
White wire from motor start capacitors goes to TSA2.
Blue wire (R or L133) from Sweep Reverse Switch goes to common terminal strip.
(Where white wire came from.)



* Drawing modified October 2009 to show correct wire colours from C1-24T and SWSR.